

GUANGDONG DETECTION CENTER OF MICROBIOLOGY

REPORT FOR ANALYSIS

Report №.	2020FM29236R01E			
Name of Sample	Air sterilization humidifier			
Applicant	Foshan Nanhai Keri Electronic Co.Ltd.			
Test Type	S. Entrustment Test			
60 :160 :160 :160 :160 :160 100 :160 :160 :160 :160 :160	长 五			
	检验检测专用章			

Address: Building 66, No.100 Central Xian Lie Road, Guangzhou, China

Postcode: 510070

Tel: +86 20 87137666

Fax: +86 20 87137668

Website: www.gddcm.com



GUANGDONG DETECTION CENTER OF MICROBIOLOGY

REPORT FOR ANALYSIS

Report №::2020FM29236R01E Verification Code: 92371480



			EDW-MI MID.I.T.L				
Name of Sample	Air sterilization humidifier	Test Type	Entrustment Test				
Applicant	Foshan Nanhai Keri Electronic Co.Ltd.	Address	13th Keyun North Road, B Zone,Shishan Science park,Nanha Foshan City ,Guangdong ,China				
Sample Source	Submitted for Testing by the Applicant	Sample Quantity	Two Samples Submitted				
Spec and Lot № of Sample	KD001	State and Characteristic	Machine				
Sample Received Date	2020-10-22	Test Completion Date	2020-11-09				
Test Standard and Method	Refer to Technical Standard for Disinfection (2002 Ministry of Health P.R.China)- 2.1.5.8						
Item Tested	Validation of disinfection efficacy of sterilization and disinfection instruments						
Ter Ter Ter Ter	io Childo Childo Childo Childo Childo						
restind restind	Testing Testing Testing Testing						
Griter Griter Grif	The test data of the sample(s) is attached to the page(s) of this report.						
Test Conclusion							
Testilio Testilio Testilio Gritto Gritto Grit	Chito Chito Chito Chito Chito Chito	Issu	ne Date: 2020-12-04				
<u> </u>			(Official Seal)				
Remarks	Manufacturer:Foshan Nanhai Keri Electronic Co.Ltd.(provide) b						

Editor:

Wuqiuyan.

Verifier:

Li Sujuan

Approver: Xe Xinhan



GUANGDONG DETECTION CENTER OF MICROBIOLOGY

ANALYSIS AND TEST RESULT

Report №: 2020FM29236R01E

1. Sample pretreatment: The carrier was glass sheet, placed it 100mm of the prototype's fog mouth, and the test was carried out after the prototype's sterilization module continued to work for 30min. The working time was 60min.

2. Test Result:

Test germ	Test group	Average cfu of positive controls (cfu/PCS)	Average cfu of testing groups (cfu/PCS)	Killing rate (%)	Sterilization logarithm
Run Run Run Run	6 ² 1	1.2×10 ⁶	3.4×10^4	97.17	1.55
Staphylococcus aureus ATCC 6538	2	1.1×10 ⁶	3.1×10 ⁴	97.18	1.55
	300	1.3×10 ⁶	3.1×10 ⁴	97.62	1.62

(Blank below)







Report №.: 2020FM29236R01E

Notice Items

- 1. The Test report is invalid if not affixed with Authorized Stamp of Test and Paging Seal.
- 2. The Test report is invalid without signature of verifier and approver.
- 3. The Test report is invalid if being supplemented, deleted or altered.
- 4. Without prior written permission, the report cannot be reproduced, except in full.
- 5. Unless otherwise stated, the results shown in this test report refer only to the sample(s) submitted.
- 6. Any dispute of the report must be raised to the testing body within 15 days after the report is received, exceeding which the dispute will not be accepted.
- 7. For the tested sample(s) submitted by the applicant, the sample information in the test report is provided by the applicant and the laboratory is not responsible for its authenticity.
- 8. This test report is for reference only to the applicant and does not have a proof of effect for others.